



ФІТИНГ HR



Тиск, бар	Код	ØA ØD	CH	L	E	ØB
350	HR18	G1/8"	14	24	8	3.5
400	HR14	G1/4"	19	32	11	4.7
400	HR38	G3/8"	22	35	12	7.9
350	HR12	G1/2"	27	41	14	11.1
315	HR34	G3/4"	32	47	16	16.7
250	HR1	G1"	41	54	19	22.2
210	HR114	G1 1/4"	50	58	20	28.6
185	HR114	G1 1/2"	55	64	22	33.3
165	HR2	G2"	70	74	25	46



Тиск, бар	Код	ØA	ØD	CH	L	E	ØB
350	HR14-18	G1/4"	G1/8"	14	24	8	3.5
400	HR38-14	G3/8"	G1/4"	19	32	11	4.7
400	HR12-14	G3/8"	G1/4"	22	35	12	7.9
350	HR12-38	G1/2"	G3/8"	27	41	14	11.1
315	HR34-38	G3/4"	G3/8"	32	47	16	16.7
315	HR34-12	G3/4"	G1/2"	32	47	16	16.7
250	HR1-12	G1"	G1/2"	41	54	19	22.2
250	HR1-34	G1"	G3/4"	41	54	19	22.2
210	HR114-34	G1 1/4"	G3/4"	50	58	20	28.6
185	HR114-1	G1 1/2"	G1"	55	64	22	33.3
165	HR2-114	G2"	G1 1/4"	70	74	25	46
165	HR2-112	G2"	G1 1/2"	70	74	25	46