


ФІТИНГ HRM



Тиск, бар	Код	ØF2	ØF1	S1	ØD1	L1	L2	L3
400	HRM38-18	G3/8"	G1/8"	22	22	22.5	12	9
400	HRM12-18	G1/2"	G1/8"	27	27	24	14	9
400	HRM12-14	G1/2"	G1/4"	27	27	24	14	13
315	HRM34-1/4	G3/4"	G1/4"	32	32	26	16	13
315	HRM34-38	G3/4"	G3/8"	32	32	26	16	14
315	HRM1-14	G1"	G1/4"	41	40	29	18	14
315	HRM1-38	G1"	G3/8"	41	40	29	18	14
315	HRM1-12	G1"	G1/2"	41	40	29	18	16
315	HRM114-12	G1 1/4"	G1/2"	50	50	32	20	16
315	HRM114-34	G1 1/4"	G3/4"	50	50	32	20	18
250	HRM112-12	G1 1/2"	G1/2"	55	55	36	22	16
250	HRM112-34	G1 1/2"	G3/4"	55	55	36	22	18
250	HRM112-1	G1 1/2"	G1"	55	55	36	22	20